

感谢您使用芝杜 zidoo 旗下产品，您可以关注我们的社交平台账号，
和我们一起交流与分享。

Thank you for choosing products of Zidoo. Friend us on
WeChat or Weibo to communicate and share with us.



微信公众号 @ **zidoo**
WeChat Official Account



微博账号 @ 芝杜官方
Weibo Account



Facebook @ **zidoottv**



Twitter @ **zidoottv**

如需更多帮助，请访问芝杜 zidoo 官网的用户论坛进行咨询。

If you need more assists, please visit user forum of the official
website of Zidoo for consultation.



官网网址 /Official website: www.zidoo.tv

目录 /Content

01	Z1000 PRO 硬件介绍	
	设备接口	P1
	装载硬盘	P3
	设备连接	P4
	性能参数	P6
02	初始化	P7
03	OTA 系统升级	P9



01	Introduction to Hardware of Z1000 PRO	
	Device Interface	P13
	Installation of Hard Disk	P15
	Specification	P16
	OTA System Update	P18
02	Initialization	P19
03	OTA System Update	P21

Z1000 PRO 硬件介绍


设备接口

Zidoo Z1000 PRO 配备有丰富的音视频输入输出接口及数据传输接口，请参考本手册内容。


1. 正面




2. 左侧



3. 右侧



4. 背面




注意:

- * 请在断电的状态下装载\更换硬盘，如是全新硬盘，请格式化后装载。
- * 请不要将任何东西遮挡散热风扇孔。
- * 请不要接触液体，以免流入设备内部造成损坏。
- * 非指定维修人员，请不要拆开机壳。

装载硬盘

Z1000 PRO 搭载 3.5 寸硬盘仓，内置 SATA 高速传输接口，无需借助任何工具，将硬盘 SATA 接口朝里轻松推入即可装载（硬盘最大支持 14TB）。




注意：请勿在设备通电的状态下装载或更换硬盘，以免造成设备或硬盘数据损坏，如果是全新硬盘，请先格式化硬盘再装载至设备，本机支持硬盘格式为：EXT3,EXT4,NTFS,FAT32,EXFAT。

设备连接

1. HDMI 连接电视


① 将设备断电，请务必保证电视机与机顶盒都在断电的状态下操作。




② 在 TV 断电的状态下将 HDMI 线一头插入设备的 HDMI OUT、一头插入电视 HDMI IN 接口。




③ 电源连接：本设备内置电源，请将随机附赠的电源线加入本机的 AC 电源插座，将电源线的另一头接入交流 110~240V 的电源插座后，打开 AC 电源插座上的电源开关。



④ 按下机器前面板的开机按钮或按下遥控器电源键进行开机，并打开电视机。



⑤ 电视选择对应的视频源。



2. AV 线连接电视

连接方式同 HDMI 线的连接方式。

Z1000 PRO 性能参数

前置显示	LED
机身	铝合金
系统	Android 9.0
CPU	Realtek RTD1619 ARM Cortex-A55(六核)
GPU	ARM Mali-G51 MP3
内存	2GB DDR4
内部储存器	32GB eMMC
Wifi 网络	2.4G+5G 双频 WiFi, 802.11 a/b/g/n/AC 2T2R MIMO 867Mbps
有线网络	1*RJ-45 以太网插孔 (10/100 / 1000Mbps)
HDMI 输出	HDMI 2.0a, 最高支持 4K@60p, HDR, 12Bit, YCbCr 4:4:4 色域空间, 支持音频源码透传
HDMI 输入	HDMI 2.0, 支持 4K@60p, PCM 音频
视频解码	4K@60p HEVC/H.265 12Bit HDR10, HDR10+, 杜比视界
音频解码	支持次世代高清音频源码直通, 解码立体声
智能控制	手机 APP 控制, RS-232, TCP/IP 控制 (支持网络唤醒)
SATA	1*SATA 3.0, 1*HDD Bay
USB	2*USB 3.0, 2*USB 2.0
电源	100-240V ~ 50/60Hz Max 1.3A
其他接口	1* 红外接收器, 1*RCA 视频, 1*RCA 左右声道 1* 同轴, 1*SPDIF 光纤 (2CH, 5.1CH), 1*RS232

初始化

正式使用机器前，本软件将为您进行第一次初始化设置，请根据初始化设置流程设置您的设备，以获得最佳的观影体验。


1. 系统语言

根据个人需要设置系统语言。



2. 屏幕缩放

通过遥控器左右键或鼠标中键滑轮调整屏幕显示范围到合适的大小。



3. 网络设置

设置相关网络配置，让机器快速连接网络。网络分为无线网络和有线网络，选择其中一种连接成功即可。



无线网络 (WIFI)：选择网络 SSID，输入密码，连接 WIFI 即可完成设置。
有线网络：无需其他操作，只需插入网线即可自动联网。网络设置完成后点击下一步了解主界面功能即可完成整个设备的初始化。



OTA 系统升级

芝杜 Zidoo 会不定期更新固件。

在 APPS 应用中心找到系统升级图标点击打开；支持在线网络升级及本地升级两种方式；勾选自动检测最新版本后，您将会自动收到最新的系统升级提示。



1. 在线升级


点击“在线升级”选项，获取在线升级信息。




2. 本地升级

用户可通过在论坛或官网手动下载升级文件，通过本地升级的方式自行升级系统。

将下载好的升级文件拷贝到 U 盘，通过点击“本地升级”选项，选择升级文件。




通过在线升级或本地升级下载完升级文件后，通过点击“升级”选项，开始升级。




系统会自动检验升级文件是否完整。



注意：自动进入系统升级，该过程请不要断电。



升级完成，自动重启系统。



特别说明：



为了保证用户体验，芝杜 Zidoo 会不定期更新固件。因此，本说明书的操作说明，有可能会与产品实际使用情况稍有出入。

Introduction to Hardware of Z1000 PRO


Device Interface

Zidoo Z1000 PRO is equipped with audio and video input & output ports and data transmission ports. Please refer to the descriptions in this manual.


1. Front




2. Left



3. Right



4. Back




Note:

- *Please load/change the hard disk after turning off the power. If it is a brand-new hard disk, Please load it after formatting it.
- *Please prevent the orifice of the cooling fan from being blocked.
- *Do not touch any liquid in case the liquid runs into the inner part of the device and damage it.
- *Any maintenance personnel who are not appointed are not allowed to open the case.

Load the Hard Disk

Z1000 PRO is equipped with 3.5 inches HDD Bay and high speed SATA transmission port. The hard disk can be loaded by pushing with hand. (The maximum hard disk supports 14 TB)




Note: Do not load or change the hard disk while the power is on vto avoid damage of the device or hard drive data. If it is a brand-new hard disk, please format it before loading it to the device. This device supports hard disk of the following formats: EXT3, EXT4, NTFS, FAT32, EXFAT.

Device Connection

1. Connect HDMI Cable to TV


1) Cut off the power. Please make sure the power of the TV and STB are off.




2) When the TV is turned off, please connect HDMI OUT port on Zidoo to HDMI IN port on TV.




3) Connect with the power. This device is equipped with suitable AC power adapter. Please connect the head of AC power adapter to the AC power input port of this device, then insert the plug of AC power adapter into the socket of 110V -240V.



4) Press the power button on the front panel of the device or press the power button on remote control to turn it on. And then turn on the TV.



5) Corresponding video source is selected on TV.



2. Connect AV Cable to TV

The connection method is same as connecting HDMI cable.

Z1000 PRO Specification


Front Display	LED
Shell	Aluminum Alloy
OS	Android 9.0
CPU	Realtek RTD1619 ARM Cortex-A55 (Hexa-core)
GPU	ARM Mali-G51 MP3
Memory	2GB DDR4
Internal Storage	32GB eMMC
WIFI	2.4G + 5G dual-band WiFi, 802.11 a/b/g/n/AC 2T2R MIMO 867Mbps
Ethernet	1*RJ-45 Ethernet Jack (10/100/1000Mbps)
HDMI Out	HDMI 2.0a, support up to 4K @ 60p, HDR, 12Bit, YCbCr 4:4:4 color range, support audio pass-through
HDMI In	HDMI 2.0, support 4K@60p, PCM audio
Video Decoder	4K@60p, HEVC/H.265, 12Bit, HDR10, HDR10+, Dolby vision
Audio Decoder	Support high-definition audio pass-through and audio decode
Intelligent Control	Mobile APP control, RS-232, TCP/IP control and WOL support
SATA	1*SATA 3.0, 1*HDD Bay
USB	2*USB 3.0, 2*USB 2.0
Power Supply	100-240V ~ 50/60Hz Max 1.3A
Other interface	1*IR Receiver, 1*RCA Cvbs, 1*RCA Audio L/R Channels, 1*Coaxial, 1*SPDIF(2CH, 5.1CH), 1*RS232

Initialization

Before actually using this device, you will be provided with this software for the first initialization. Please set your device according to the initialization process to obtain the optimum watching experience.


1. System Language

Select the language of the system as you want.




2. Screen Scaling

Adjust the screen display range using LEFT or RIGHT button of the remote control (Mouse Wheel) so that the image can be appropriately displayed on the screen of the TV.




3. Network Setting

Set the configuration of the network so that the device can quickly connect with the network. The network includes WIFI network and Ethernet network. Select either of them and successfully connect with it.



WIFI: Select SSID and enter password, connect to WIFI and finish setting.

Ethernet Network: Insert the network cable and then Internet will be connected automatically. After completing the network setting, it will show "Set success" and enter into Home Page. Initialization setting is finished.



OTA System Update


Zidoo will update the firmware aperiodicity.

Find the update icon in APPs center and click it, online network update and local update are supported. After ticking "Automatically detect the latest version", you will receive the prompt for the latest firmware update automatically.




1. Online Update

Click "Online Update" to obtain information of online update.




2. Local Update


Users can download the update files on the forum or official website and update firmware through files.
Copy the downloaded update file to USB disk. Click "USB update" to select the update file.




Download the update file by online update or local update. Click "Update" to update it.



The system will automatically check the update file whether is completed or not.



Note: Automatically access to system upgrade. Please don't power off in the progress.



Once the update process is completed, the system will automatically restart.



Special Note:

To guarantee user experience, Zidoo will update the firmware aperiodicity. Therefore, this manual may not be totally in line with the product.

Guarantee 保修卡

User File 用户信息

User name 用户姓名		Sex 性别	
Address 回寄地址			
Telephone 联系电话		Zip 邮编	
Commodity name and specification 产品名称		Model NO. 型号	
Fault description 故障说明			

Guarantee Item 保修条款

- (1) One year guarantee from date of purchased. (not including fittings)
- (2) All of damage by man-made(tear open the housing,tear off the sticker,unnormally using),or losing this card,we will not guarantee.
- (1) 保修期限：本产品遵循国家三包条例，商品存在非人为损坏所引起的硬件故障，本公司将提供一年保修服务（配件除外）。
- (2) 如需寄回本公司维修，请与此保修卡一同寄回。
- (3) 一切人为因素造成的损坏（包括擅自拆机，撕毁标签，自行刷机等等），本公司将不予保修。





QUALIFIED
CERTIFICATE
合格证

CHECKER/ 检验员 _____

DATE/ 日期 _____

